



Work Steps:

(A) For Sheetrock with wood wall stud

First Step

Please use a stud finder (or other technique) and a pencil. After locating the stud mark the center of the stud, which will hold the product.

Second Step

Bring the product in final position and mark the screw-points on the center of the studs.

Third Step

Use your drill and the 1/16" bit to make pilot holes for maximum 2 inch to all markings.

Fourth Step

Mount the metal holder with enclosed screws to the stud and make sure the screws are fastened securely.

Fifth Step

Screw the thread rod into the end caps.

Final Step

Connect the post with the end cap through the holders in the wall.

(B) For Sheetrock without wood wall stud

First Step

Bring the product in final position and mark the screw-points in desired location.

Second Step

Drill 3/16" holes, be sure to keep the drill level.

Third Step

Insert drywall anchors (not included) into drilled holes (some anchors might require a hammer). Be careful not to break the sheetrock.

Fourth Step

Attach provided brackets to wall and secure trough drilled holes. Double check if brackets are level and fastened.

Fifth Step

Screw the thread rod into the end caps.

Final Step

Connect the post with the end cap through the holders in the wall.

Advice:

Please note the secure assembly and mounting requires one adult person.